

fittingmadeeasy

....for rollers....


What you will need...

- minimum of 4 **screws** and 4 appropriately-sized **rawl plugs** if screwing into masonry
- a **screwdriver** to match your screws
- a **power drill**
- a **pencil**

Step One...(Please read all instructions before starting)

Inside Recess – Decide whether to fit to the window frame (**FACE FIX**), or whether to fit to the lintel (**TOP FIX**). We recommend **TOP FIX** if the window frame is **uPVC**, or if there are any **obstructions** in the way (catches, handles etc.)


Outside Recess – If fitting outside the recess, measurements C will need to be the same. To work out C, minus B from A and divide the answer by 2. Follow instructions for **FACE FIX**.




FACE FIX TOP FIX

Step Two... Hint: Please take care with the bottom bar (it can slide out!)

FACE FIX – Attach the **appropriate brackets** to each end of the blind, and offer the blind into the **fixing position**. Use your **pencil** to mark the four holes (2 on each bracket).



TOP FIX – Make a mark of any **protruding handles**. Attach the appropriate brackets to each end of the blind, and offer the blind into the fixing position 6cm into the recess from the handles. Use your pencil to mark the four holes (2 on each bracket).



Step Three...

The **“cross” bracket** will be fixed onto your **“controls” side**. Drill the two holes per bracket where marked and screw brackets into position.


Step Four...

Fit the blind into the brackets by first sliding the **“pin”** end of the blind into its bracket. Then, slide the other **“blue”** end into its bracket, ensuring the **blue hook** is **facing down** when placed into the bracket (the gear of the sidewinder should be visible only when looking underneath the blind).

Final Step...

The sidewinder will be on the left or right as you have chosen. Pull the chain to raise or lower the blind to the desired height. It will remain in that position automatically. **Enjoy your blinds!**

WARNING: For safety reasons, please keep all cords and chains out of the reach of children. All beds, cots and other furniture need to be moved away from the blinds.



Need Help? Phone our helpline:
01204 854 112



blinds made easy
quality made to measure blinds for the home